

Power OFF/ON procedures

1) JHS-180

SORT: NORTH / RANGE		UTC11:43
BRG	RANGE	NAME/MMSI
270°	: 0.18NM	JRC MARU1
35°	: 0.29NM	JRC MARU2
22°	: 0.92NM	JRC MARU3
PASSWORD		****

Turning the power OFF

Press **OFF**, and then the password input display (the left figure) appears.

Input the four-figure password using ten-key, and then press **ENT**. Default password is "0000"

After "PRESS AND HOLD [PWR]+[OFF]" appears by matching the inputted password, press and hold **PWR/DIM** and **OFF** (around for two second) until turning the power OFF.

"PRESS AND HOLD [PWR]+[OFF]" does not appears if the inputted password was incorrect.

Turning the power ON

Press and hold **PWR/DIM** around for one second to turn the power ON, and then other ship list appears.

2) JHS-182

MAIN MENU		UTC11:44
BRG : RNG	NAME / MMSI	
270°	: 0.18NM	OCEAN-LINE
35°	: 0.29NM	QUEEN
* 22°	: 0.92NM	ABCDEFGH-MARU
PASSWORD :		* * * *
ABCDEFGHIJKLMNOP ↑ QRSTU V WXYZ.0123 456789[_] "#\$%&' ()?@+-*/^`;<=>!	[EXIT]	
	[ENT]	

Turning the power OFF

Press **OFF**, and then the password input display (the left figure) appears.

Input the four-figure password using the software keyboard on the lower part of the display. Default password is "0000"

(Select 0 and then press the jog dial four times.)

Select [ENT] by jog dial and then press the jog dial.

After "PRESS AND HOLD [PWR]+[OFF]" appears by matching the inputted password, press and hold **PWR/DIM** and **OFF** (around for one second) until turning the power OFF.

"PRESS AND HOLD [PWR]+[OFF]" does not appears if the inputted password was incorrect.

Turning the power ON

Press and hold **PWR/DIM** around for one second to turn the power ON.

Around five seconds later, "LOADING" display appears, and around 40 seconds later, other ship list appears.